

RELEASE HOOKS

DROP TESTING

Release hooks help determine the ability of a product or container to withstand impact loads which may be imposed upon such items during normal transit conditions. L.A.B. Equipment, Inc.'s release hooks can accommodate large and bulky items.

TEST WITH CONFIDENCE

Release hooks provide an efficient and ergonomic method of determining the ability to withstand the impacts of handling and shipment. The effects of manual stacking, loading, and dropping are easily duplicated through the ability of laboratory controlled drop tests.

Features

- Applicable for dropping loads of various configurations and dimensions
- Includes an enclosed foot activated drop switch
- Ruggedly constructed from steel and aluminum components

Options

- Extended electrical cord

DROP
with
CONFIDENCE



Payload Capacity	3000 lbs or 1360 kg
Operating System	Electrically Operated
Construction	Solid Steel and Aluminum Components
Cable Length	13 foot cables from release hook to drop switch
Utility Requirement	100-120V/10Amp or 200-240/5Amp 50-60 Hz